www.dreamcheeky.com

# USB ON THE AIR COMMUNICATOR USER MANUAL

## Minimum system requirements for running the Dream Cheeky USB On The Air Communicator:

- Microsoft Windows 2000 SP4/ XP SP2 or later / Vista
- One available USB port

## Before using the product, carefully read this manual and retain it for future reference.

Contents:

USB On The Air Communicator X 1

## USB Connection

Connect the USB cable of On The Air Communicator to a USB port located on your PC prior to play with it.

1. Plug the On The Air Communicator into your PC-USB port.




**Note:** Using a USB HUB or docking station may result in the loss of power to the USB On The Air Communicator.
This could make the Unit not work properly.

## To play the On The Air Communicator

Connect the USB cable attached to the USB On The Air Cimmunicator to a USB port located on your PC prior to play with it.




Please make sure the software (e.g. Skype,MSN) is open when using the USB On The Air Communiator.
For details setting, please refer to the instruction of the softwares.

**Precautions:**
Before using this product, carefully read this manual and retain it for future reference.

**Safety:**
This product has been designed with the highest concern for safety.
However, any electrical device, if used improperly, has the potential of causing fire, electrical shock or personal injury. To help ensure accident-free operation, follow these guidelines:
Stop use, unplug the USB cord, immediately if the device functions in an abnormal manner, produces unusual sounds or smells or becomes too hot.

**Use and Handling**
1. Do not expose the product to high temperatures, high humidity, or direct sunlight.
2. Do not expose the product to dust, smoke or steam.
3. Do not allow small particles to get into the product.
4. Do not place the product on surfaces that are unstable or subject to vibration.
5. Do not throw or drop the product or subject it to physical shock.

**Cleaning:**
1. For safety reasons, unplug the USB cord from your PC before cleaning.
2. Wipe gently with a damp cloth, and then dry the surface.
3. Do not use solvents or other chemicals to clean the exterior of On The Air Communicator.

**General:**
1. Should the product perform unexpected function, unplug the unit and then restart the software.

**Note:** See **www.dreamcheeky.com** for full online support link and trouble-shooting.